Guide to check connection to AuraDB

This guide helps you to check off potential problems when connecting to AuraDB from neo4j browser, or neodash.

Step 1: Check browser connection:

1. Launch any of these three browsers: Chrome, Firefox, and Edge.




2. If you have any extensions, you can disable them through these steps:




3. Then go into manage extensions




4. Once inside, toggle the extensions off by clicking on the circled buttons below



5. Once done, try to connect to the AuraDB with neo4j browser again:




6. When successfully connect to AuraDB, you should see the following:



Step 2: Check incoming connection with PowerShell If Step 1 did not help you, then we will check your computer connections to see if it is accepting incoming connections.


1. Launch Windows Powershell from the search bar



2. Then copy this code below to check:

Test-NetConnection < DBID > .databases.neo4j.io -Port 7687


The DB ID can be found here:



3. You should see the following result after pressing Enter

```
Windows PowerShell
Windows PowerShell
Copyright (C) Microsoft Corporation. All rights reserved.
Try the new cross-platform PowerShell https://aka.ms/pscore6
PS C:\Users\mdhdo> Test-NetConnection 012308d3.databases.neo4j.io -Port 7687
                 : 012308d3.databases.neo4j.io
ComputerName
RemoteAddress
                   7687
RemotePort
InterfaceAlias
                   Ethernet
                   192,168,1,18
SourceAddress
                   True
TcpTestSucceeded :
```

4. If your result does not have the last line as "TcpTestSucceeded: True", then we will have to configure your - Windows Defender Firewall - . Search for that application and open it.




5. Once inside, go to "Advance settings". Note here that this requires an admin privileged account, shown by the shield icon.




Security and Maintenance Network and Sharing Centre

See also


6. Open the advanced settings, and select "Inbound Rules". Then "New Rule" on the right side




7. Once here, select "Port", then "Next"




8. Then specify the connection to "TCP", then select "Specific local ports" and enter 7687 as the port to open for incoming connections




9. Once next, select "Allow the connection" and then "Next"




10. Enable the connections then click next



11. Finally, we need to name this rule so we can find it next time we want to change it:



12. After doing this, try to connect to AuraDB again, through the browser and you should see the same screens as above.



13. When successfully connect to AuraDB, you should see the following:

